

## 7 AH Configuration tool

Tool for configuring Idesco's 125 kHz readers



## Features and benefits

- Time-saver: Fast, convenient, reader programming before installing
- Powerful: Create your own custom reader configurations as detailed as you desire
- Enhance Security: Custom configure parameters to stymie cloning and tampering

7 AH Coder software opens up the full spectrum of configurable features exploitable in your Access 7 AH reader. This convenient, user-friendly application enables you to deeply configure your reader precisely to the parameters you've chosen (from the w i d e variety available) before installing it. Parity, data length, Clock & Data, LED colour, buzzer mode, optical tamper, the list is long – all are modifiable by AH Coder and can help enhance your reader's security.

**Technical specifications** 

Minimum system requirements	Microsoft Windows XP (Service Pack 3) / Windows 7 .Net Framework 3.5 or newer Processor: 1GHz Pentium processor or equivalent (Minimum) RAM:1 Gt (Minimum); 2Gt (Recommended) Display: 1024 x 768 high color, 32-bit (Minimum) USB drive
Configuration tool to PC interface	USB
Configuration tool to reader interface	RS-232
Package contains	7AH Configuration Tool 7AH Configuration Tool User manual USB Stick including the following: 1. 7AH Conf SW 2. 7AH Conf SW User Manual 7AH Connection board

Idesco Oy reserves the right to revise this publication and to make changes to its content as well as the right to change or discontinue these products, at any time, without obligation to notify any person or entity of such revisions or changes. All trademarks and registered trademarks are property of their respective owners. 8.7.2015. C00638E v.1.02.