

CL Coder



DESKTOP

95 x 62 x 24 mm

CL Coder programming tool is used to create configurations for 8 CL 2.0 reader family. Configurations can be send to 8 CL 2.0 readers directly through RS-232 interface, or user can create configuration card which is then used with 8 CL 2.0 readers.

Minimum system requirements

Operating system	Microsoft Windows 7 with .Net Framework 4.5 or newer
Processor	1GHz Pentium processor or equivalent (Minimum)
RAM	1GB (Minimum)
Display	1024 x 768 high color, 32-bit (Minimum)
	USB port

Supported transponders

MIFARE® DESFire EV1 & EV2 & EV3 (13,56 MHz)

Package contains

CL Coder Application
User Manual
Installation Instructions
9 CD 2.0 Desktop reader/writer for programming cards
3 pcs Mifare DESFire cards (13,56 MHz)

Idesco Oy reserves the right to revise this publication and to make changes to its content as well as the right to change or discontinue these products, at any time, without obligation to notify any person or entity of such revisions or changes. All trademarks and registered trademarks are property of their respective owners.
14.6.2024. C00935E v1.00.

Idesco Oy

Elektroniikkatie 4
90590 Oulu
Finland

Tel. +358 (0)20 743 4175
Email info@idesco.fi
idesco.fi

